

## **LOADING AIR TRAC SOFTWARE on the BANTAM**

1. Insert a USB into an office computer. Ideally the USB is empty.
2. Copy the entire zip file from your computer onto the USB.
3. Go to the USB directory, highlight the zip file, right click on it and choose EXTRACT ALL. Accepting the option of installing it to its own folder on the USB.
4. Once this is done, you can exit from the USB page and remove the USB. Take the USB to the plane and install the USB in your CPU.
5. Power up the Bantam and instead of going into Air Trac choose the option to go into Windows.
6. Double click on My Computer. You should see the USB as a D, E or F drive.
7. Double click on the D drive so you can see contents.
8. Double click on the Air Bantam folder.
9. Double click on the Air Bantam file that will be there.
10. Accept the install prompts.
11. The software will self load.
12. If the menu for the USB is still open - you can click X to go out or alternately press File on the left and then choose CLOSE.
13. Once back to Windows desktop, You can double click the Air Trac Touchscreen icon to begin Air Trac.